


KitchenAid®

UPPER OVEN PARTS

For Model: KEBS276BBL2, KEBS276BWH2
(BLACK) (WHITE)

SUPERBA
27" BUILT-IN ELECTRIC
DOUBLE OVEN
Self Clean Upper and Lower Oven



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Model: KEBS276BBL2, KEBS276BWH2

(BLACK) (WHITE)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			16	3179848	Clip, Oven Seal	33	3179587	Retainer, Seal
1	3185085	Button, Plug	17	3177681	Bracket, Switch	34		Vent, Middle Trim
2	3177545	Bracket, Mounting	18	3177923	Insulator, Switch		3187883	Black Model
3	3177623	Cabinet, Back	19	3177621	Bottom, Module		3187885	White Model
	3185647	Screw	20	3179220	Rail, Support (2)		3179776	Screw (8)
6	3178143	Cabinet, Top		3185647	Screw		3188645	Screw (6)
	3185647	Screw	21		Side Trim, Door (2)		4168863	Screw (6)
7	3183748	Top, Module		3187875	Black Model	35	3183791	Vent, Tube
	3185647	Screw		3187878	White Model	39	4168203	Cover, Cap Tube
8		Side, Cabinet	22	3177434	Support, Oven		4159445	Screw
	3177440	Left Hand		3185647	Screw	40	4163883	Plate, Cover
	3177438	Right Hand	23	3178612	Shield, Radiation	41	3183752	Bracket, Mounting Control Panel
9	3186684	Tube, Vent		3185647	Screw	FOLLOWING PARTS NOT ILLUSTRATED		
	3185648	Screw (3)	24	3177433	Bracket, Hinge	INSULATION		
10	3150505	Oven Light Assy.		3179795	Screw (6)			
11	3184533	Gasket, Light		3185647	Screw			
12	311255	Bulb, Oven Light	26	3177560	Back, Module			
				3185647	Screw			
14	3186950	Frame, Front	27	3185562	Liner, Oven			
15	3179813	Seal, Door	28	3178298	Hinge, Door (2)			
			31	4173553	Switch, Door			
				4159117	Nut (2)			
				313489	Screw (2)		4454418	Insulation, Wrap


OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
SPLICING WIRES--25FT. LENGTH			PAINT, TOUCH-UP (1/2oz.)			PAINT, BULK (1 qt.)		
		18 Ga. 80 °c Rating		72017	White		799344	White
	350806	Yellow		72107	Almond		978883	Almond
		16 Ga. 80 °c Rating		72110	Harvest Gold		261891	Harvest Gold
	242829	Blue		72112	Toast		285367	Toast
		14 Ga. 150 °c Rating		72113	Platinum		285368	Platinum
	242820	Black		72032	Black	ADHESIVE		
	242821	Blue		261869	Citrine White		482338	Sealer, Silastic (3 Oz.)
	242822	Brown	PAINT, PRESSURIZED SPRAY (13 oz.)				591014	Adhesive, Loctite (1/3 Oz.)
	242823	Green				ACCESSORY PARTS		
	242824	Orange		350930	White		799832	Kit, Porcelain Repair (White)
	242825	Red		350956	Almond		832985	Rack, Cooking (Bi-Level)
	242826	White		261890	Harvest Gold			
	242827	Yellow		285365	Toast			
		14 Ga. 200 °c Rating		285366	Platinum			
	242830	Brown		830864	Black			
	242831	Red		350942	Primer			
	242832	Yellow		350941	Leveler (Primer)			
		12 Ga. 150 °c Rating						
	242828	Black						
	242829	Red						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS

For Model: KEBS276BBL2, KEBS276BWH2
(BLACK) (WHITE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS

For Model: KEBS276BBL2, KEBS276BWH2

(BLACK) (WHITE)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

3	3183748	Top, Module
	3185647	Screw
4	3186684	Tube, Vent
	3185648	Screw (3)
5	3185562	Liner, Oven
7	311255	Bulb, Oven Light
8	3184533	Gasket, Light
9	3150505	Oven Light Assy.
12	3188161	Frame, Front
13	3179813	Seal, Door
14	3177681	Bracket, Switch
	3177991	Screw (2)
15	3177923	Insulator, Switch
16	3177551	Bottom, Oven
17	3179220	Rail, Support (2)
	3185647	Screw
18	3177433	Bracket Hinge (2)
	3179795	Screw (6)
	3185647	Screw
19	3177621	Bottom, Module
20	3178612	Shield, Radiation
	3179795	Screw (6)
	3185647	Screw
21	3177434	Support, Oven
	3185647	Screw
22	3177560	Back, Module
	3185647	Screw
24	3179848	Clip, Seal (3)
25	3178298	Hinge, Door (2)
26	3182814	Button, Plug
27	3185085	Button, Plug
28	3182159	Tube, Vent (Male)
	3185647	Screw
29	3182160	Tube, Vent (Female)
30	4173553	Switch, Door
	4159117	Nut (2)
	313489	Screw (2)
32	3179587	Retainer, Seal
33	4168203	Cover, Cap Tube
34		Trim, Lower Vent
	3177783	Black Model
	3187957	White Model
35	4163883	Plate, Cover

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION


4454418 Insulation, Wrap

CONTROL PANEL PARTS

For Model: KEBS276BBL2, KEBS276BWH2

(BLACK)

(WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4454363	Membrane, Switch
	4454364	Black Model
	4454364	White Model
2	3181889	Bracket, Mounting
		Switch Membrane
3	3181706	Microcomputer
4	3183705	Retainer, Bracket
	3182939	Screw
5	3182985	Clip, Retainer
6	3182162	Trim, Door (2)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

7	3182151	Door, Latch Handle
	3182154	Black Model
	3182154	White Model
8	3183702	Trim, Panel
	3185647	Screw
9	3184321	Bracket
	3182939	Screw
10		Frame, Control Panel
	3187954	Black Model
	3187955	White Model
11	3184567	Clip, Control Frame
	3185647	Screw
	309133	Screw

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

FOLLOWING PARTS NOT ILLUSTRATED

LITERATURE PARTS


LIT3185963	Tech Sheet
LIT3183659	Installation Instructions
LIT3188200	Use & Care Guide

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER AND LOWER OVEN DOOR PARTS

For Model: KEBS276BBL2, KEBS276BWH2

(BLACK) (WHITE)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			7	3185458	Glass, Reflective	13		Handle, Door
1	3185497	Liner, Door	8	3185438	Plate, Latch Strike		3185986	Black Model
2	3178001	Screw	9	3185439	Retainer, Glass		3185987	White Model
3	3185462	Gasket, Window		3185647	Screw	14	3182138	Spacer, Door Handle
4	3185457	Glass-Clear	10	3185459	Glass-Clear Frame, Door	15	3188599	Bushing, Door Handle
5	3188815	Insulation Retainer	11	3187850	Black Model	16	3188633	Foil-Adhesive Backed
4168863	Screw			3187852	White Model	17	3188635	Foil-Adhesive
			12	3187863	Glass, Door Black Model			
				3187865	White Model			


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LATCH AND VENT PARTS

For Model: KEBS276BBL2, KEBS276BWH2

(BLACK)

(WHITE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LATCH AND VENT PARTS

For Model: KEBS276BBL2, KEBS276BWH2

(BLACK) (WHITE)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	3183748	Module, Top
2	258076	Block, Terminal
	308043	Screw
3	3183784	Switch, Latch
	254225	Screw
4	3178668	Switch, Latch
	98106	Screw
	254225	Screw
5	3178185	Insulator, Switch
6	3177662	Guard, Latch
7		Handle, Latch
	3177969	Upper Oven
	3184037	Screw (2)
	3181963	Lower Oven
	3185414	Screw (2)
	3179116	Screw
8	3184039	Knob, Latch Handle
	3183294	Screw
10	3178410	Latch Mechanism
11	3177496	Plate, Mounting
	3177991	Screw
12	3185455	Baffle
	311773	Screw
13	3183954	Nozzle, Vent
		Bottom
14	3183955	Nozzle, Vent Top
15	3183999	Box, Vent
	4173231	Screw
	3179116	Screw
16	3183964	End, Vent Box
17	3183533	Bracket, Mounting
	3177991	Screw
18	3183720	Blower, Fan
19	3183791	Tube, Vent
	3185647	Screw
20	3149650	SPST Thermostat
	3185647	Screw
21	3183785	Shield, Heat
	3177991	Screw
22	3183953	Box, Vent
23	3183965	End, Box Vent
	3185647	Screw
24	3183793	Tube, Vent
	3185647	Screw
25	3183532	Clamp, Tube
	3185647	Screw
26	313755	Seal, Foam
27	4159035	Bushing


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Model: KEBS276BBL2, KEBS276BWH2

(BLACK)

(WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.


1	3185562	Liner, Oven
2	661415	Element, Broil
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
5	3185367	Rack, Offset
6	3185368	Rack, Oven
7	661416	Element, Bake
	3185648	Screw (2)
8	4167277	Nut, Meat Probe
9	4163975	Gasket, Meat Probe
10	4167266	Probe Cover
11	4159557	Washer
12	3179672	Spacer, Tubing
13	3150107	Meat Probe Jack
14	3150144	Meat Probe
15	313570	Clip, Tubing
19	3180694	Bracket, Element
	3185648	Screw (4)
20	3148440	Sensor, Heat
	3185648	Screw
21	3149652	SPST Thermostat
	3185647	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Model: KEBS276BBL2, KEBS276BWH2

(BLACK) (WHITE)



Illus. No.	Part No.	DESCRIPTION
1	3187607	Harness Wire (Door Switch Upper)
2	3183656	Harness Wire (Door Switch Lower)
3	3185950	Harness Wire (Lower Oven)
4	3185965	Harness Wire (Upper Oven)
5	3185952	Harness, Wire Latch Assy. (Upper)
6	3179668	Standoff, Wire Screw
7	313438	Clip, Harness
9	4159037	Clamp, Wire
10	3183361	Harness, Wire Latch Assy. (Lower)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST